

## Contents

- 1 Product    2 User Guide    3 Tools    4 Specification



- Up to 500 pin-codes programmable from keypad.
- Two access groups, each have request to exit inputs to control.
- Default value: first group= **000~249 (Relat\_A)**; second group= **250~499 (Relay\_B)**.
- 2 relay outputs contact support latching or momentary outputs.
- Built-in watchdog to prevent the system from halting.
- Built-in tamper switch, include external security system interface.
- Bell output, Press **\*** + **#** together for bell using. (Optional)
- Keypad will be locked for 30 seconds while continuous error operation.


## Specification

Users	500	Power consumption	< 2W	Memory	EEPROM	Weight(g)	100±10
Digits	3-6	Operating Temperature	-20°C to +60°C	Color	Gray/Silver	Housing Material	ABS
Power Supply	9-16VDC / 100mA	Indicator	1 Bi-Color LED&1Beeper	Dimensions(mm)	111(L) x 77(W) x 26(H)		

## Front Panel Indicators


- The unit should make a beep sound when any key on the keypad is depressed.
- If no key is made within 30 seconds, it will automatically exit the programming mode.
- In the programming mode: LED light green and flash rapidly, it means that the unit waits for entering.  
LED is red and flash rapidly, it means the reader is busy.
- One beep sound mean acknowledge, two beep sounds mean not acknowledge.

## Installation



- Pull the cables from the square hole of the mounting plate.
- Use a screwdriver to screw the base onto the wall.
- Connect the terminal cables to the body and attach the body to the mounting plate.
- Assemble the covers with the Allen key and screws (accessories supplied).
- Turn on the power and LED will light and beep will sound.

## Terminator




### CN1

Wire Application	Wire	Description
Relay_A	N.C.	1 N.C.
	N.O.	2 N.O.
	COM	3 COM
Exit Switch	EGR	4 Negative Trigger Input for Relay_A
	DLY	5 Negative Trigger Input for Relay_B
Power	VIN-	6 DC Power GND
	VIN+	7 DC Power 12V

### CN2

Wire Application	Wire	Description
Relay_B	COM	1 COM
	N.O.	2 N.O.
	N.C.	3 N.C.
T a m p e r Switch	SW	4 N/O or N/C select via jumper
	SW	5 COM
SGND	SGND	6 Signal Ground

## Wiring Diagram



### Installation Notice

- Don't equip controller and lock with the same power supply.
- The power for controller may be unstable when the lock is activating, that may make the controller malfunction.
- The standard installation: Door relay and lock use the same power supply, and controller use independent power supply.

## Delete user(s) code and Enable to system

### Delete (Remove) a User Code from the system

Press **\*** 123456 **#** (or Master Code) → 14 **\*** UUU **#** → Done ( A green light and beep means that the user code was deleted. )  
[e.g.] Delete User address 10 : Access programming mode → 14 **\*** 010 **#** → Done

### Delete (Remove) all Users Codes from the system

Press **\*** 123456 **#** (or Master Code) → 29 **\*** 29 **\*** **#** → Done (The LED flash red during 1 second to mean that the system is deleting all user codes. Then a green light and beep means that all user codes were deleted. )

### Delete (Remove) a User Code from the controller

If you would like to delete all user codes. Remove the AR-721KP from the mounting plate. Press and hold the reset switch 10 seconds (RESTER, on the KEYPAD circuit board). LED light green during 5 seconds and six beep sounds mean that all user are deleted.

### • Delete (suspend) a (range of) User(s) Code from the system

Press \*123456 # (or Master Code) → 10 \* SSS \* EEE # → Done (A green light and beep means that the user code(s) was disabled. )

[e.g.] Delete (suspend) User code 58 :

Access programming mode → 10 \* 058 \* 058 # → Done

[e.g.] Delete (suspend) User code 1 to 10 :

Access programming mode → 10 \* 001 \* 010 # → Done

### • Enable a (range of) User(s) Code to the system

Press \*123456 # (or Master Code) → 11 \* SSS \* EEE # → Done (A green light and beep means that the user code(s) was enabled. )

[e.g.] Enable User code 58 to the system :

Access programming mode → 11 \* 058 \* 058 # → Done

[e.g.] Enable User code 1 to 10 to the system :

Access programming mode → 11 \* 001 \* 010 # → Done

## Programming

### A. Entering and Exiting Programming Mode

#### • Entering

Input \*123456 # or \*PPPPPP #

[e.g.] The Default Value= 123456, if already changed the Master Code= 876112, input \*876112 # → Access programming mode

#### • Exiting

Input \* #

#### • Changing the Master Code

Access programming mode → 09 \* PPPPPRRRRR # [Input the 6-digit new master code twice.]

[e.g.] If want to changing the Master Code= 876112, input \*123456 # → 09 \*876112876112 #

#### • Factory Reset by its commands

If the master code is forgotten it can be restored to the factory default. Remove the AR-721KP from the mounting plate. Press and hold the reset switch 5 seconds. LED light green during 2.5 seconds and five beep sounds mean that master code have restored to the factory default 123456.

### B. Set up user number corresponding to door relay

Access programming mode → 01 \* UUUU \* UUUU=User address (Default value = 0250)

[User number 0000~0249 operates Relay\_A; User number 0250~0499 operates Relay\_B.]

### C. Add a User Code to the system

Access programming mode → 12 \* UUU \* PPPPP #

UUU(User address) : 001~254 ; PPPPPP(User Code) : The user code must be 3 to 6 digits in length and the key # cannot be used in a code.

[e.g.] Set user code 123 to user 001 :

Access programming mode → 12 \* 001 \* 123 # → Done

[e.g.] Set user code 123456 to user 002 :

Access programming mode → 12 \* 002 \* 123456 # → Done

### D. Set the door relay-1 release time

Access programming mode → 02 \* TTT #

└ Set door relay\_B, enter 03.

TTT = 000 Latch(Toggle) / TTT = 001~600 (001~600) seconds.

TTT =601~609 (0.1~0.9) seconds.

### E. Set time out value

Access programming mode → 04 \* TT #

TT = 00~09 (0~0.9) seconds; TT = 10~49 (1~4.9) seconds

### F. Set keypad lock of continuous error operation

Access programming mode → 05 \* T # T = 3~9 (times); T = 0 (Close this Function)

[e.g.] Set three incorrect user code are entered : Access programming mode → 05 \* 3 # → Done

### G. Set Door bell ( \* + # Door Ring)

Access programming mode → 06 \* PPP #

PPP = 000 (Disable) / PPP = 001 (Enable) [If use two access groups, places set **disable**.]

## Command List

Function	Command	Exposition
Entering programming mode	* PPPPPP #	PPPPPP: Master Code, (Default value: 123456)
Exiting programming mode	* #	
User number corresponding to door relay	01 * UUUU #	UUUU=User address, (Default value: 0250); User before the 250 <sup>th</sup> is the first group, the other is the second group.
Relay_A time setting	02 * TTT #	TTT=Door relay time ; 000 (Output constantly) 001~600=1-600 Sec. ; 601~609=0.1~0.9 Sec.
Relay_B time setting	03 * TTT #	TTT=Door relay time ; 000 (Output constantly) 001~600=1-600 Sec. ; 601~609=0.1~0.9 Sec.
Set time out value	04 * TT #	TT=Keypad operate during time Range : 00 ~ 09 (0 - 0.9) Sec. ; 10 ~ 49 (1 - 4.9) Sec.
Set keypad lock of continuous error operation	05 * T #	T=Continuous error times : 3 ~ 9 (Times) ; T=0 (Disable)
Door bell	06 * PPP #	PPP=000 ( Disable ) / PPP=001 ( Enable )
Master code settings	09 * PPPPPRRRRR #	PPPPPP= New master code RRRRRR= Repeat the new master code
Suspend or delete user code	10 * SSS * EEE #	SSS= starting user address ; EEE= ending user address
Recover user code	11 * SSS * EEE #	SSS= starting user address ; EEE= ending user address
Add a User Code to the system	12 * UUU * PPPPP #	UUU=User address PPPPPP=3 to 6 digits
Delete (Remove) a User Code	14 * UUU #	UUU=User address
Delete (Remove) all Users Codes	29 * 29 * #	